



Install the Hub Mounting Bracket to the wall.




Connect the Hub cable to the power circuit wires, then connect the wired cable to the Hub.

STEP 13




Slide down the hub on the plate to attach it to the wall.



Locate compliant positions for Smoke Alarm installation(s) and attach power cables to underside of alarms, if hard wiring is required.




INVENTED IN AUSTRALIA | MADE IN CHINA



Install Alarm using provided mounting anchors and screws.





Water Leak Detector.



STEP 18


STEP 14






STEP 19

STEP 15








Press "Full Test" and wait up to five minutes for all Alarms to sound.


STEP 20



STEP 21

Add notes and photos as required, and press "Complete Job".






CONTENTS

- 1. Sensor Hub
- 2. Base Plate
- 3. Power Plug
- 4. Bag of mounting anchors and screws
- 5. Sensor Smoke Alarm
- 6. Alarm dust cover
- 7. Bag of mounting screws and anchors

TOOLS REQUIRED:





Sensor Hub app on your smartphone




Turn on the power by pushing it towards the top.



STEP 2


Login to the Sensor Global App.



Scan the Hub QR code with the app and wait up to 5 minutes for the right hand side hub light to turn solid blue.

HUB BOX CONTENTS:















Refresh the hub on the app to update the connected status.




Open the Alarm and remove the battery tab.



STEP 6

Close and re-open to power on. A beep sound will indicate power on.



To put the smoke alarm into pairing mode, double-tap TEST button on alarm and check for a small orange light that will start flashing within the ring.

SMOKE ALARM BOX CONTENTS:



Power plug





Alarm dust cover




Bag of mounting anchors and screws












Turn off the power circuit connected to the hub installation location, and turn off the power circuit to any existing hard wired alarms that are being replaced or installed. Tip: Install the hub near an existing power point in a low traffic area of



Using the mounting bracket to guide where the hole is best placed, drill a 30mm diameter hole in the wall for Hub wiring, 200mm minimum distance from the right hand side wall or other object.